

The wire supplied is for the 12 volt feed to your power antenna. Follow the manufacturer's instructions for circuitry and hookup locations.

P:\INST\PA-23